



Acer Aspire 5742 CMOS Battery Replacement

This guide will show you how to remove and replace your CMOS battery located in your laptop.

Written By: Anthony Foster



INTRODUCTION




Removal of the CMOS battery is a very quick and simple procedure. The CMOS battery will lose its charge over time and cannot be recharged, therefore you will need to replace it from time to time (very infrequently). No special caution is needed to follow this guide other than to be gentle with the laptop and do not to touch any electrical components not mentioned in the guide.



TOOLS:



- [Phillips #00 Screwdriver](#) (1)
 - [Spudger](#) (1)
-

Step 1 — Cover Panel




- Turn the notebook around to face you.
- There are two Phillips #00 screws securing the cover panel to the rest of the notebook. Remove these screws.

Step 2





- Use a spudger to release the panel from the plastic retaining clips keeping it in place.
- ⚠ Do not apply too much force, or you may break the clips.
- Remove the panel and set it aside.

Step 3 — CMOS Battery



- i** After removing the cover panel, you will see the hard drive, the RAM, and the CMOS battery.
- The CMOS battery is the silver coin-like object in the center.

Step 4



- Press the tip of the spudger underneath the CMOS battery with very slight force.
- Press down on the opposite side of the battery while prying the battery upward with the spudger.
- After the battery is mostly lifted from the slot, you may pull out the battery with your fingers.

To reassemble your device, follow these instructions in reverse order.

